


# DHO800<sub>Series</sub> Digital Oscilloscope

Data Sheet

DSA36101-1110 Jul. 2023

# DHO800 Series Digital Oscilloscope

## Compact Size, Various Interfaces



7" Capacitive Multi-touch Screen

265.35 mm (W) × 161.75 mm (H) ×77.38 mm (D)

# Application Scenarios

It is compact and portable, easy to be used on the workbench, in the classroom, on the test site, and in other application scenarios.

Its compact and delicate design makes it easy to carry and operate. You can put it on the workbench, with supporting legs folded or unfolded; put it flat on the workbench; or fix its rear panel to the desktop clamp-on stand to save room.

#### 🕑 Technical Advantage

#### 12-bit High Resolution



#### Type-C Interface

**12-bit** vertical resolution provides 4096 vertical digitizing levels16 times the vertical digitizing level of the

8-bit resolution

Easy for users to test and see the small signals



Provides power with the mobile power supply via this interface, making the on-site test more flexible.

# Application



The bus error and too much locking may lead to problems in the embedded design. The DHO800 series is equipped with a standard configuration of protocol triggers and decodes, capable of capturing the bus event accurately to check whether the serial communication link between devices runs properly.



When troubleshooting a failed component, we need to quickly locate the problem and make some modifications. With the auto measurement, math operation, protocol trigger and decode, the DHO800 series enables you to debug the problems with a high speed and locate the problem accurately.



The DHO800 series offers professional user experience at an affordable entry-level price. The brand new DHO800 series supports touch screen operation and the traditional convenient panel operation. It is an ideal high-precision oscilloscope with 12-bit measurement accuracy at an affordable price for your lab.

# **Product Features**

#### **Product Features**

- Ultra-low noise floor, purer signal, never miss the small signals
- Up to 12 bits resolution for all the models of this series
- Max. analog bandwidth of 100 MHz, 4 analog channels, external trigger output (std.) available for the dual-channel model
- Max. real-time sample rate of 1.25 GSa/s
- Max. memory depth of 25 Mpts
- Vertical sensitivity range: 500 μV/div to 10 V/div
- Max. capture rate of 1,000,000 wfms/s (in UltraAcquire mode)
- Digital phosphor display with real-time 256-level intensity grading
- Waveform search and navigation function allows you to debug the signal anomalies faster
- 7" (1024x600) capacitive multi-touch screen
- Brand new Flex Knob brings user-friendly experience
- USB Device & Host, LAN, and HDMI interfaces (std.) for all the models of this series
- Novel and delicate industrial design, easy to operate
- Unique online upgrade

The DHO800 series is RIGOL's new launched high-performance economical digital oscilloscope. Though compact in design, it has superior performance. It features a capture rate up to 1,000,000 wfms/s (in UltraAcquire Mode), 25 Mpts memory depth, 12 bits resolution, and low noise.

The DHO800 series is a brand new economical digital oscilloscope designed for the vast mainstream digital oscilloscope market to meet their design, debugging, and test demands.

# RIGOL Probes and Accessories Supported

Model	Туре	Description
Passive High-imp	edance Probe	
PVP2150	Passive High- impedance Probe	<ul> <li>Attenuation: 10:1/1:1</li> <li>1X BW: DC to 35 MHz</li> <li>10X BW: DC to 150 MHz</li> <li>Compatibility: All models of RIGOL's digital oscilloscopes</li> </ul>
PVP2350	Passive High- impedance Probe	<ul> <li>Attenuation: 10:1/1:1</li> <li>1X BW: DC to 35 MHz</li> <li>10X BW: DC to 350 MHz</li> <li>Compatibility: All models of RIGOL's digital oscilloscopes</li> </ul>
PVP3150	Passive High- impedance Probe	<ul> <li>Attenuation: 10:1/1:1</li> <li>1X BW: DC to 20 MHz</li> <li>10X BW: DC to 150 MHz</li> <li>Compatibility: All models of RIGOL's digital oscilloscopes</li> </ul>
ligh-voltage Sin	gle-ended Probe	
RP1010H	High-voltage Probe	<ul> <li>Attenuation: 1000:1</li> <li>BW: DC to 40 MHz</li> <li>DC: 0 to 10 kV DC</li> <li>AC: pulse ≤20 kVp-p</li> <li>AC: sine ≤7 kV<sub>rms</sub></li> <li>Compatibility: All models of RIGOL's digital oscilloscopes</li> </ul>
RP1018H	High-voltage Probe	<ul> <li>Attenuation: 1000:1</li> <li>BW: DC to 150 MHz</li> <li>DC+AC<sub>peak</sub>: 18 kV CAT II</li> <li>AC<sub>rms</sub>: 12 kV CAT II</li> <li>Compatibility: All models of RIGOL's digital oscilloscopes</li> </ul>

Model	Туре	Description
RP1300H	High-voltage Probe	<ul> <li>Attenuation: 100:1</li> <li>BW: DC to 300 MHz</li> <li>CAT I 2000 V (DC+AC)</li> <li>CAT II 1500 V (DC+AC)</li> <li>Compatibility: All models of RIGOL's digital oscilloscopes</li> </ul>
High-voltage Differe	ntial Probe	
<b>РНА0150</b>	High-voltage Differential Probe	<ul> <li>BW: DC to 70 MHz</li> <li>Max. voltage ≤ 1500 Vpp</li> <li>Compatibility: All models of RIGOL's digital oscilloscopes</li> </ul>
PHA1150	High-voltage Differential Probe	<ul> <li>BW: DC to 100 MHz</li> <li>Max. voltage ≤ 1500 Vpp</li> <li>Compatibility: All models of RIGOL's digital oscilloscopes</li> </ul>
<b>рна2150</b>	High-voltage Differential Probe	<ul> <li>50X BW: DC to 160 MHz</li> <li>500X BW: DC to 200 MHz</li> <li>Max. voltage ≤ 1500 Vpp</li> <li>Compatibility: All models of RIGOL's digital oscilloscopes</li> </ul>
- 6 6 0 RP1025D	High-voltage Differential Probe	<ul> <li>BW: DC to 25 MHz</li> <li>Max. voltage ≤ 1400 Vpp (DC + AC P-P)</li> <li>Compatibility: All models of RIGOL's digital oscilloscopes</li> </ul>
RP1050D	High-voltage Differential Probe	<ul> <li>BW: DC to 50 MHz</li> <li>Max. voltage ≤ 7000 Vpp (DC + AC P-P)</li> <li>Compatibility: All models of RIGOL's digital oscilloscopes</li> </ul>
RP1100D	High-voltage Differential Probe	<ul> <li>BW: DC to 100 MHz</li> <li>Max. voltage ≤ 7000 Vpp (DC + AC P-P)</li> <li>Compatibility: All models of RIGOL's digital oscilloscopes</li> </ul>

Model	Туре	Description
Current Probe		
		<ul><li>BW: DC to 300 kHz</li><li>Maximum Input</li></ul>
		AC: ±100 A
	Current Probe	AC P-P: 200 A
RP1001C		<ul><li>AC RMS: 70 A</li><li>Compatibility: All models of RIGOL's digital oscilloscopes</li></ul>
		<ul><li>BW: DC to 1 MHz</li><li>Maximum Input</li></ul>
		AC: ±70 A
	Current Probe	AC P-P: 140 A
RP1002C		<ul><li>AC RMS: 50 A</li><li>Compatibility: All models of RIGOL's digital oscilloscopes</li></ul>
		<ul><li>BW: DC to 50 MHz</li><li>Maximum Input</li></ul>
		AC P-P: 50 A (non-continuous)
in the second	Current Probe	AC RMS: 30 A
RP1003C		<ul> <li>Compatibility: All models of RIGOL's digital oscilloscopes</li> </ul>
		Required to order RP1000P power supply.
		BW: DC to 100 MHz
90		Maximum Input
and the second sec	Current Probe	AC P-P: 50 A (non-continuous)
RP1004C	Current Hobe	<ul> <li>AC RMS: 30 A</li> <li>Compatibility: All models of RIGOL's digital oscilloscopes</li> <li>Required to order RP1000P power supply.</li> </ul>
		BW: DC to 10 MHz
RP1005C		Maximum Input
	Current Probe	AC P-P: 300 A (non-continuous), 500 A (@pulse width ≤ 30 us)
	Current Hobe	<ul> <li>AC RMS: 150 A</li> <li>Compatibility: All models of RIGOL's digital oscilloscopes</li> <li>Required to order RP1000P power supply.</li> </ul>

\_\_\_\_

\_\_\_\_\_

\_\_\_\_

Model	Туре	Description
-00		<ul> <li>BW: DC to 2 MHz</li> <li>Maximum Input AC P-P: 700 A peaks, non-continuous</li> </ul>
RP1006C	Current Probe	<ul> <li>AC RMS: 500 A</li> <li>Compatibility: All models of RIGOL's digital oscilloscopes</li> <li>Required to order RP1000P power supply.</li> </ul>
RIGOL Brown route neitre Control of the second Control of the seco	4CH Power Supply	Power supply for RP1003C, RP1004C, RP1005C, and RP1006C; supporting 4 channels.
RP1000P		

# Specifications

All the specifications are guaranteed except the parameters marked with "Typical" and the oscilloscope needs to operate for more than 30 minutes under the specified operation temperature.

#### **Overview of the DHO800 Series Technical Specifications**

Model	DHO802	DHO804	DHO812	DHO814
Analog Bandwidth (-3 dB)	70 MHz		100 MHz	
Rise Time (10% to 90%, typical)	≤5 ns		≤3.5 ns	
No. of Analog Channels	2 + EXT	4	2 + EXT	4
Sampling Mode	Real-time Sampling	9		
Max. Sample Rate of Analog Channel	four-channel mode	channel <sup>[1]</sup> ), 625 MS el:	a/s (full-channel <sup>[3]</sup> ) a/s (dual-channel <sup>[2]</sup>	), 312.5 MSa/s
Max. Memory Depth	Two-channel model: 25 Mpts (single-channel <sup>[1]</sup> ), 10 Mpts (full-channel <sup>[3]</sup> ) four-channel model: 25 Mpts (single-channel <sup>[1]</sup> ), 10 Mpts (dual-channel <sup>[2]</sup> ), 1 Mpts (full- channel <sup>[3]</sup> )			
Max. Waveform Capture Rate	30,000 wfms/s (Vector Mode) 1,000,000 wfms/s (UltraAcquire Mode)			
Vertical Resolution	12 bits			
Hardware Real-time Waveform Recording and Playing	Max. 500,000 frames			
Peak Detection	Capture 1.6 ns glitches			
LCD Size and Type	7'' capacitive multi-touch screen			
Display Resolution	1024x600			

### Vertical System Analog Channel

Vertical System Analog	g Channel	
Input Coupling		DC, AC, or GND
Input Impedance		1 MΩ ± 1%
Input Capacitance		15 pF ± 3 pF
Probe Attenuation Coefficient		0.001X, 0.002X, 0.005X, 0.01X, 0.02X, 0.05X, 0.1X, 0.2X, 0.5X, 1X, 2X, 5X, 10X, 15X, 20X, 50X, 100X, 150X, 200X, 500X, 1000X, 1500X, 2000X, 5000X, 10000X, 15000X, 20000X, and 50000X
		CAT I 300 V <sub>rms</sub> , 400 V <sub>pk</sub> (DC + V <sub>peak</sub> )
Maximum Input Voltage	Remarks	Whether the probe is used or not, the transient overvoltage is not allowed to occur.
		Please use the instrument dedicated for the specified measurement category (not applicable to CAT II, III, and IV)
Vertical Resolution		12 bits
Vertical Sensitivity Range <sup>[4]</sup>		500 μV/div to 10 V/div
		±0.5 V (<500 μV/div)
		±1 V (≥500 μV/div, ≤65 mV/div)
Offset Range		±8 V (>65 mV/div, ≤270 mV/div)
		±20 V (>270 mV/div, ≤2.75 V/div)
		±100 V (>2.75 V/div, ≤10 V/div)
Dynamic Range		±4 div (12 bits)
Bandwidth Limit (Typical)		20 MHz, FULL; selectable for each channel
		± 1% (>5mV/div, FullScale)
DC Gain Accuracy <sup>[4]</sup>		± 2% (≤5mV/div, FullScale, Typ.)
DC Offset Accuracy		$\leq$ 200 mV/div (±0.1 div ± 2 mV ± 1.5% of offset value)
		>200 mV/div ( $\pm 0.1$ div $\pm 2$ mV $\pm 1.0\%$ of offset value)
Channel-to-Channel Isolation		≥100:1
ESD Tolerance		±8 kV (on input BNCs)

#### Horizontal System--Analog Channel

Horizontal SystemAnalog Channel			
Range of Time Base		5 ns/div to 500 s/div	
		Fine	
Time Base Resolution		100 ps	
Time Base Accuracy		±25 ppm ± 5 ppm/year	
Time Pace Delay Papae	Pre-trigger	-5 div	
Time Base Delay Range	Post-trigger	1 s or 100 div, whichever is greater	
Delta Time Accuracy		±(Time Base Accuracy x Readout) ± (0.001 x Screen Width) ± 20 ps	
Channel-to-Channel Skew Correction		±100 ns, Accuracy ± 1 ps	
Analog Channel-to-Channel Delay (Typical) <sup>[5]</sup>		≤2 ns	
	YT	Default	
	XY	Channel 1/2/3/4	
Horizontal Mode	SCAN	Time base ≥200 ms/div	
	ROLL	Time base $\geq$ 50 ms/div, available to enter or exit the ROLL mode by adjusting the horizontal timebase knob	

#### Acquisition System

Two-channel model:
1.25 GSa/s (single-channel <sup>[1]</sup> ), 625 MSa/s (full-channel <sup>[3]</sup> )
four-channel model:
1.25 GSa/s (single-channel <sup>[1]</sup> ), 625 MSa/s (dual-channel <sup>[2]</sup> ), 312.5 MSa/s (full-channel <sup>[3]</sup> )
Two-channel model:
25 Mpts (dual-channel <sup>[2]</sup> ), 10 Mpts (full-channel <sup>[3]</sup> )
four-channel model:
25 Mpts (single-channel <sup>[1]</sup> ), 10 Mpts (dual-channel <sup>[2]</sup> ), optional: 1 Mpts (full-channel <sup>[3]</sup> )

Acquisition System		
Acquisition Mode	Normal	Default
	Peak Detection	Capture 1.6 ns glitches
	Average Type	2, 4, 8, 1665536 are available for you to choose
	UltraAcquire	Waveform capture rate up to 1,000,000 wfms/s

## Trigger System

Trigger System		
Trigger Source		Analog channel (CH1 to CH4), EXT TRIG <sup>[6]</sup>
Trigger Mode		Auto, Normal, Single
	DC	DC coupling trigger
	AC	AC coupling trigger
Trigger Coupling	High Frequency Rejection	Cut-off frequency to 120 kHz (internal trigger only)
	Low Frequency Rejection	Cut-off frequency to 120 kHz (internal trigger only)
Noise Rejection		Increases delay for the trigger circuit (internal trigger only), On/Off
Holdoff Range		8 ns to 10 s
Trigger Bandwidth		Internal trigger: analog bandwidth of the oscilloscope
Trigger Sensitivity		Internal trigger: 0.5 div, $\geq$ 50 mV/div; 0.7 div (with noise rejection enabled)
		External trigger <sup>[6]</sup> : 500 mVpp (DC to 100 MHz)
Trigger Level Range		Internal trigger: ±4.5 div from the center of the screen External trigger <sup>[6]</sup> :±5 V

### Trigger Type

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_

Trigger Type	
Trigger Type	Edge trigger, Pulse trigger, Slope trigger, Video trigger, Pattern trigger, Duration trigger, Timeout trigger, Runt trigger, Window trigger, Delay trigger, Setup/Hold trigger, Nth Edge trigger, RS232/UART, I2C, SPI
Edge	Triggers on the threshold of the specified edge of the input signal. The edge types can be Rising, Falling, or Either.
	Source channel: CH1 to CH4, and EXT <sup>[6]</sup>
Pulse	Triggers on the positive or negative pulse with a specified width. The pulse width is greater or smaller than a certain value or within a certain time range.
	Source channel: CH1 to CH4
Slope	Triggers on the positive or negative slope of the specified time. The slew time is greater or smaller than a certain value or within a certain time range. Source channel: CH1 to CH4
Video	Triggers on all lines, specified line, odd field, or even field that conforms to the video standards. The supported video standards include NTSC, PAL/SECAM, 480p/60Hz, 576p/50Hz, 720p/60Hz, 720p/50Hz, 720p/30Hz, 720p/25Hz, 720p/24Hz, 1080p/60Hz, 1080p/60Hz, 1080p/50Hz, 1080p/30Hz, 1080p/25Hz, 1080p/24Hz, 1080i/60Hz, and 1080i/50Hz.
	Source channel: CH1 to CH4
Pattern	Identifies a trigger condition by searching for a specified pattern. The pattern is a combination of multiple selected channel sources. The logic pattern of each channel is H, L, X, Rising, or Falling.
	Source channel: CH1 to CH4
Duration	Triggers when the specified pattern meets the specified duration condition. The pattern is a combination of multiple selected channel sources. The logic pattern of each channel is H, L, and X. The duration is greater or smaller than a certain value, or within a certain time range, or outside a certain time range. Source channel: CH1 to CH4
Timeout	Triggers when duration of a certain event exceeds the specified time. The event can be specified as Rising, Falling, or Either. Source channel: CH1 to CH4
Runt	Triggers when the pulses pass through one threshold but fail to pass through another threshold. Source channel: CH1 to CH4
Window	Triggers in a specified window state when the rising edge of the signal crosses the upper threshold or the falling edge crosses the lower threshold. The window state can be Enter, Exit, or Time. Source channel: CH1 to CH4

Trigger Type	
Delay	Triggers when the time difference between the specified edges of Source A and Source B meets the preset time. The duration is greater or smaller than a certain value, or within a certain time range, or outside a certain time range. Source channel: CH1 to CH4
Setup/Hold	When the setup time or hold time between the input clock signal and the data signal is smaller than the specified time. Source channel: CH1 to CH4
Nth Edge	Triggers on the Nth edge that appears after the specified idle time. The edge can be specified as Rising or Falling. Source channel: CH1 to CH4
RS232/UART	Triggers on the Start, Error, Check Error, or Data frame of the RS232/UART bus (up to 20 Mb/s). Source channel: CH1 to CH4
12C	Triggers on the Start, Stop, Restart, MissedACK, Address (7 bits, 8 bits, or 10 bits), Data, or Address Data of the I2C bus. Source channel: CH1 to CH4
SPI	Triggers on the specified pattern of the specified data width (4 to 32) of SPI bus. CS <sup>[7]</sup> and Timeout are supported. Source channel: CH1 to CH4

### Search&Navigation

Search&Navigation		
Туре	Edge, Pulse	
Source	Analog channel	
Сору	Copies the search settings from or to the trigger settings mutually, including threshold setting and search condition settings	
Result Display	Displays in event table form; can be exported to the external or internal memory	
	Time navigation: navigates to the acquired waveforms in time order.	
Navigation	Event navigation: uses the navigation keys to scroll through the event search results and navigates to the specified event.	
	Frame navigation: navigates to the specified frame segment in UltraAcquire mode.	

#### **Waveform Measurement**

#### **Waveform Measurement** Number of 2 pairs of XY cursors Cursors Voltage deviation between cursors ( $\Delta Y$ ) Manual Mode Time deviation between cursors ( $\Delta X$ ) Reciprocal of $\Delta X$ (Hz) (1/ $\Delta X$ ) Fixes Y-axis to track X-axis waveform point's voltage and time values Track Mode Cursor Fixes X-axis to track Y-axis waveform point's voltage and time values Auto Allows to display cursors during auto measurement Measurement Measures the voltage parameters of the corresponding XY Mode channel waveforms in XY time base mode. X = Channel 1, Y = Channel 2 Number of 41 auto measurements; and up to 10 measurements can be Measurements displayed at a time. Measurement CH1 to CH4, Math1 to Math4 Source Measurement Main, Zoom Range (Region) Displays 33 measurement items (vertical and horizontal) for All the current measurement channel; the measurement results Auto Measurement are updated continuously. Measurement Vmax, Vmin, Vpp, Vtop, Vbase, Vamp, Vupper, Vmid, Vlower, Vertical Vavg, VRMS, Per. VRMS, Overshoot, Preshoot, Area, and Period Area. Period, Frequency, Rise Time, Fall Time, +Width, -Width, +Duty, -Duty, Positive Pulse Count, Negative Pulse Count, Rising Edge Horizontal Count, Falling Edge Count, Tvmax, Tvmin, +Slew Rate, and -Slew Rate Delay( $A\uparrow-B\uparrow$ ), Delay( $A\uparrow-B\downarrow$ ), Delay( $A\downarrow-B\uparrow$ ), Delay( $A\downarrow-B\downarrow$ ), Others Phase( $A\uparrow-B\uparrow$ ), Phase( $A\uparrow-B\downarrow$ ), Phase( $A\downarrow-B\uparrow$ ), and Phase( $A\downarrow-B\downarrow$ )

#### Waveform Calculation

Waveform Calculation			
No. of Math Functions		4 math functions available to be displayed at a time	
Operation		A+B, A-B, A×B, A/B, FFT, A&&B, A  B, A^B, !A, Intg, Diff, Sqrt, Lg, Ln, Exp, Abs, AX+B, LowPass, HighPass, BandPass, and BandStop	
Color Grade		Supports FFT	
FFT	Record Length	Max. 1 Mpts (The max. number of the points to be analyzed for the FFT operation is 1 Mpts.)	
	Window Type	Rectangular, Blackman-Harris, Hanning (default), Hamming, Flattop, and Triangle.	
	Peak Search	A maximum of 15 peaks, determined by the user-defined threshold and offset threshold	

#### Waveform Analysis

Waveform Analysis			
Waveform		Stores the signal under test in segments according to the trigger events, that is, saves all the sampled waveform data as a segment to the RAM for each trigger event. The maximum number of the sampled segments reaches 500,000.	
Recording	Source	All enabled analog channels	
	Analysis	Support playing frame by frame or continuous playing; capable of calculating, measuring, and decoding the played waveforms	
PassFail		Compares the signal under test with the user-defined mask to provide the test results: the number of successful tests, failed tests, and the total number of tests. The pass/fail event can enable immediate stop, beeper, and the screenshot.	
	Source	Any analog channel	

Waveform Anal	lysis	
		The waveform histogram provides a group of data, showing the number of times a waveform hits within the defined regio range on the screen. The waveform histogram not only shows the distribution of hits, but also the ordinary measurement statistics.
	Source	Any analog channel, auto measurement item
Histogram	Туре	Horizontal, vertical, and measure
		Statistics: Sum, Peaks, Max, Min, Pk_Pk
	Measure	Histogram: Mean, Median, Mode, Bin width, Sigma, and XSca
	Sampling Mode	Supports all modes, except the Zoom, XY, and ROLL modes
		Provides a dimensional view for waveform intensity, color grade >16, 256-level color scale display
Color Grade	Source	Any analog channel
	Color Theme	Temperature and intensity
	Sampling Mode	Supports all modes
Serial Deco	ding	
Serial Decoding		

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_

\_\_\_\_\_

Number of Decodings	4 protocol types can be decoded and enabled at the same time		
Decoding Type	Standard: Parallel, RS232/UART, I2C, SPI		
Parallel	Up to 4 bits of Parallel decoding, supporting any analog channel Support user- defined clock and auto clock settings. Source channel: CH1 to CH4		
RS232/UART	Decodes the RS232/UART (up to 20 Mb/s) bus's TX/RX data (5-9 bits), parity (Odd, Even, or None), and stop bits (1-2 bits) Source channel: CH1 to CH4		
I2C	Decodes the address (with or without the R/W bit) of the I2C bus, data, and ACK. Source channel: CH1 to CH4		

Serial Decoding	
SPI	Decodes the MISO/MOSI data (4-32 bits) of the SPI bus. The available mode includes "Timeout" and "CS" <sup>[7]</sup> .
	Source channel: CH1 to CH4
Auto	

Auto	
AutoScale	Min voltage > 10 mVpp, duty cycle > 1%, frequency > 35 Hz

#### **Digital Voltmeter**

<b>Digital Voltmeter</b>	
Source	Any analog channel
Function	DC, AC+DC <sub>rms</sub> , AC <sub>rms</sub>
Resolution	ACV/DCV: 3 digits
Limits Beeper	Sounds an alarm when the voltage value is within or outside of the limit range

### **High-precision Frequency Counter**

High-precision Fre	equency Counter	
Source		Any analog channel and EXT <sup>[6]</sup>
Measure		Frequency, period, totalizer
Counter	Resolution	3-6 digits, user-defined
	Max. Frequency	Max. analog bandwidth
Totalizer		48-bit totalizer
		Counts the number of the rising edges
Time Reference		Internal reference

#### **Command Set**

Command Set	
Common Commands Support	IEEE488.2 Standard
Error Message Definition	Error messages

Command Set	
Support Status Report Mechanism	Status Reporting
Support Syn Mechanism	Synchronization
Display	
Display	
LCD	7-inch capacitive multi-touch screen, gesture enabled operation
Resolution	1024×600 (Screen Region) 16:9
Graticule	10 horizontal divisions x 8 vertical divisions
Persistence	Off, Infinite, variable persistence (100 ms to 10 s)
Brightness	256 intensity levels (LCD, HDMI)
Processor System	
Processor	
10003301	Cortex-A72 up to 1.8 GHz, 6-core processor
	Cortex-A72 up to 1.8 GHz, 6-core processor 4 GB RAM
System Memory	
System Memory Operating System	4 GB RAM
System Memory Operating System Internal Non-volatile Memory	4 GB RAM Android
System Memory Operating System Internal Non-volatile Memory	4 GB RAM Android
System Memory Operating System Internal Non-volatile Memory I/O	4 GB RAM Android
System Memory Operating System Internal Non-volatile Memory //O I/O USB2.0 Host	4 GB RAM Android 8 GB
System Memory Operating System Internal Non-volatile Memory I/O USB2.0 Host USB2.0 Device LAN	4 GB RAM Android 8 GB 1 on the front panel

Web Remote Control

EXT Interface<sup>[6]</sup> Trigger Input 1 on the front panel, BNC connector

the oscilloscope into the Web browser to display the

operation interface of the oscilloscope)

<mark>I/O</mark>

AUX OUT	Output Interface	1 on the rear panel, BNC connector Vo (H) $\ge$ 2.5 V open circuit, $\ge$ 1.0 V 50 $\Omega$ to GND Vo (L) $\le$ 0.7 V to load $\le$ 4 mA, $\le$ 0.25 V 50 $\Omega$ to GND
	Trigger Output	Outputs a pulse signal when the oscilloscope is triggered
	Pass/Fail	Output a pulse signal when a pass/fail event occurs. Supports user-defined pulse polarity and pulse time (100 ns to 10 ms)
HDMI	Video Output	1 on the rear panel, HDMI 1.4, A plug. It is used to connect to an external monitor or projector
Probe Compensation Output		1 kHz, 3 V <sub>pp</sub> square waveform

## **Power Supply**

Power Supply	
Power Supply Interface	Туре-С
Power Voltage	DC 12 V, 4 A
Power	Max. 48 W (when connected to various interfaces, USB storage device, active probes)

#### Environment

on)
ation)
ation)
)

## Warranty and Calibration Interval

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Warranty and Calibra	ation Interval		
Warranty	Three years for the mainframe, excluding the probes and accessories.		
Recommended Calibration Interval	18 months		
Regulations			
Regulations			
	Compliant with EMC DIRECTIVE 2014/30/EU, compliant with or higher than the standards specified in IEC 61326-1:2013/EN 61326-1:2013 Group 1 Class A		
	CISPR 11/EN 55011		
	IEC 61000-4-2:2008/EN 61000-4-2	±4.0 kV (contact discharge), ±8.0 kV (air discharge)	
	IEC 61000-4-3:2002/EN 61000-4-3	3 V/m (80 MHz to 1 GHz); 3 V/m (1.4 GHz to 2 GHz); 1 V/m (2.0 GHz to 2.7 GHz)	
Electromagnetic Compatibility	IEC 61000-4-4:2004/EN 61000-4-4	1 kV power line	
	IEC 61000-4-5:2001/EN 61000-4-5	0.5 kV (phase-to-neutral voltage); 1 kV (phase-to-earth voltage); 1 kV (neutral-to- earth voltage)	
	IEC 61000-4-6:2003/EN 61000-4-6	3 V, 0.15-80 MHz	
	IEC 61000-4-11:2004/EN 61000-4-11	Voltage dip: 0% UT during half cycle; 0% UT during 1 cycle ; 70% UT during 25 cycles	
		short interruption: 0% UT during 250 cycles	

Regulations	
	EN 61010-1:2019
	EN 61010-031:2015
	IEC 61010-1:2016
	IEC 61010-2-030:2017
Safety	UL 61010-1:2012 R7
	UL 61010-2-31:2017 R2
	CAN/CSA-22.2 No. 61010-1-12:2017
	CAN/CSA-22.2 No. 61010-2-30:2018
	CAN/CSA-22.2 No. 61010-031-07:201
Vibration	Meets GB/T 6587; class 2 random
VIDIATION	Meets MIL-PRF-28800F and IEC60068-2-6; class 3 random
	Meets GB/T 6587-2012; class 2 random
Shock	Meets MIL-PRF-28800F and IEC 60068-2-27; class 3 random
	In non-operating conditions: 30 g, half-sine wave, 11 ms duration, 3 shocks along the main axis, total of 18 shocks

#### **Mechanical Characteristics**

Mechanical Characteristics		
Dimensions	265.35 mm (W) x 161.75 mm (H) x 77.38 mm (D)	
Woight <sup>[8]</sup>	Package excluded: 1.78 kg	
Weight <sup>[8]</sup>	Package included: 2.78 kg	

#### Non-volatile Memory

Non-volatile Memory				
	Setup/Image	setup (*.stp), image (*.png, *.bmp, *.jpg)		
Data/File Storage	Waveform Data	CSV waveform data (*.csv), binary waveform data (*.bin,), list data (*.csv), and reference waveform data (*.ref, *.csv, *.bin)		
Internal Capacity		8 GB		
Reference Waveform		Displays 10 internal waveforms		
Setting		Storage is limited by the capacity		

#### **Non-volatile Memory**

**USB** Capacity

## Supports the USB storage device that conforms to the industry standard

#### Note:

[1]: Single-channel mode: If any one of the channels is enabled, it is called single-channel mode.

[2]: Dual-channel mode: For four-channel models, if any two of the channels are enabled, it is called dual-channel mode.

[3]: Full-channel mode: For two-channel models, if all of the two channels are enabled, it is called full-channel mode; for fourchannel models, if any three channels or all of the four channels are enabled, it is called full-channel mode.

[4]: 500 µV/div is a magnification of 1 mV/div setting. For vertical accuracy calculations, use full scale of 8 mV.

[5]: For any channel, under the same input impedance with DC-coupled, the Volts/div setting is the same for 100 mV/div and 200 mV/div.

[6]: Only available for the two-channel models.

[7]: Only available for the four-channel models.

[8]: Standard configuration.

# Order Information and Warranty Period

## **Order Information**

Order Information	Order No.		
Model			
100 MHz, 1.25 GSa/s, 25 Mpts, 4CH	DHO814		
100 MHz, 1.25 GSa/s, 25 Mpts, 2CH	DHO812		
70 MHz, 1.25 GSa/s, 25 Mpts, 4CH	DHO804		
70 MHz, 1.25 GSa/s, 25 Mpts, 2CH	DHO802		
Standard Accessories			
Power Adaptor Conforming to the Standard of the Destination Country			
Banana-Plug Ground Connecting Cable			
DHO814/DHO804: Passive Probe x4 (150 MHz) DHO812/DHO802: Passive Probe x2 (150 MHz)	PVP3150		


#### NOTE:

For all the mainframes, accessories and options, please contact the local office of RIGOL.

## Warranty Period

Three years for the mainframe, excluding the probes and accessories.

# Option Ordering and Installation Process



- According to the usage requirements, please purchase the specified function options from RIGOL
   Sales Personnel, and provide the serial number of the instrument that needs to install the option.
- 2. After receiving the option order, the **RIGOL** factory will mail the paper software product entitlement certificate to the address provided in the order.
- 3. Log in to RIGOL official website for registration. Use the software key and instruments serial number provided in the entitlement certificate to obtain the option license code and the option license file.
- 4. Download the option license file to the root directory of the USB storage device, and connect the USB storage device to the instrument properly. After the USB storage device is successfully recognized, the Option install menu is activated. Press this menu key to start installing the option.